



## Notes:

- 1. Each Step should be glued to the Step beneath it (PL Premium is the recommended concrete adhesive).
- 2. Each Step weighs approximately 650 pounds. It should be installed using a scissors clamp with protective rubber grips.
- 3. Care should be taken in pre-planning the rise over run of the Steps. The depth of the stair tread can be modified by changing the overlap of the step. Check local code for minimum required tread depth.

Copyright 2009 Shea Wall Systems, Inc.

Design is for internal stability of the Shea wall structure only. External stability, including but not limited to foundation and slope stability is the responsibility of the Owner. The design is based on the assumption that the materials within the retained mass, methods of construction, and quality of materials conform to Shea's specification for this project.

Disclaimer: This drawing was prepared by Shea Wall Systems, Inc. and to the best of our knowledge, accurately represents the product use in the application that is illustrated. This drawing is for conceptual, instructional, and estimating purposes only. Anyone making use of this drawing does so at their own risk and assumes all liability for such use. Final design for construction purposes must be done by a registered professional engineer who is familiar with the product and who has taken into account the specific site conditions.



**DRAWING # 201** 

## STEP BLOCK

SHEA WALL SYSTEMS, INC 87 Haverhill Street Amesbury,MA 01913 Phone: 800-696-7432 Phone: 978-388-1509

www.sheaconcrete.com